



巧克力电动滑轨

CHOCOLATE MILK SLIDER

使用说明书
User Manual

更多使用方式, 请扫码观看视频教程
Please scan the QR code to watch tutorial



bilibili



Youtube

yc.onion

YC Onion


YC Onion

yconionfilm

www.yconionmall.com

Follow us for more!

产品概览



- 1、电源指示灯
- 2、蓝牙指示灯
- 3、B键
- 4、多功能按键
- 5、A键
- 6、电池仓

- 7、快门线口
- 8、DC电源线供电口

APP下载

苹果IOS用户

App store搜索“YC Onion”即可下载使用

* 需要IOS10.0或者更高版本, 与iPhone、iPad和pod touch
兼容App语言根据系统语言发生变化


安卓Android用户

前往百度手机助手搜索“YC Onion” 即可下载使用
或前往Google play搜索“YC Onion”即可下载使用

* 需要Android5.2或更高版本, 与Android手机兼容App语言
根据系统语言发生变化


滑轨供电方式

外置电池供电



使用时将标准的佳能LP-E6电池（选配）
放入电池仓（2600可持续使用约4个小时）

移动电源供电



使用常规的移动电源，通过Type-C电源线（标配）
即可为洋葱联动电控模块供电
（10000毫安移动电源可持续使用约3小时）

模块操作方式

1、短按开关键开机

2、长按A键[3]去到预想点，

松开按钮即停按下多功能键[4]设置A点；

长按B键[5]去到预想点，

松开按钮即停按下多功能键[4]设置B点。

A点、B点位置确定后，

再按下多功能键[4]进入视频模式

（模块使用时，默认打开缓启动功能。）

3、设置完AB点后。

按下按键A[3]后，电机模块即会往A点方向运行；


按下按键B[5]，电机模块即会往B点方向运行；

4、点击多功能按键[4]调节速：快-中-慢。

工作模式

热狗三代电动模块通电后，开启手机蓝牙并打开“YC Onion”APP

在产品分类中得滑轨分类中点击该稳定器名字，进行搜索，点击设备立即连接。



规格参数

名称	巧克力电动滑轨
型号	ECS_B
尺寸	77.8*77*65mm
重量	260g
螺口标准	上3/8螺丝、底部3/8螺丝孔（默认装载1/4螺丝转接环）
包括功能	视频模式、延时摄影、四轴联动交互系统
材质	铝合金
续航时间	佳能LP-E6电池供电约3小时/10000毫安充电宝约15小时
APP兼容性	IOS10或更高版本、安卓5.1或更高版本

警告和免责声明

- 1. 对于本产品，本公司不承担终端客户对本产品所有调试和使用当中的风险和责任（包括直接、间接或者第三方的损失）；
- 2. 我公司对于任何从非正常渠道获取的产品，将不予任何服务；
- 3. 由于产品固件程序的升级和更改，有可能造成本说明书中描述的功能有变动，升级固件前请仔细阅读升级说明；
- 4. 可能存在因产品硬件升级改造后与本说明书不符的描述，请以官网发布的最新产品信息为准；
- 5. 本公司对本产品保留一切解释权利。

保修信息

用户信息

姓名 _____ 电话 _____
邮箱 _____ 地址 _____

产品信息

产品名称 _____
产品型号 _____

出厂日期 _____

保修期限 _____


保修条例

- 1. 本产品自购买日期起保修一年；
- 2. 擅自拆卸产品以及人为造成的损坏概不保修

ECS_A_UM_1.0



Product Overview




- 1、Power Indicator
- 2、Bluetooth Indicator
- 3、Button B
- 4、Multi-function Button
- 5、Button A
- 6、Battery Compartment

- 7、Cable Port
- 8、DC Power Port


Charging the Motor

External battery



Plug in the standard CANON LP-E6 battery (not included) when using the motor (2600mAh can last 4 hours)

Power Bank



Power the interlink module using standard power bank via Type-C cable (included)

APP Download



For IOS User

Download the app by searching "YC Onion" in APP Store

* Requires IOS 10.0 or later. Support Multilanguage
(More languages will continue to be updated)



For Android User

Download the app by searching "YC Onion" in Baidu Mobile Assistant Or in "Google play"


* Requires Android 5.2 or later, Support Multilanguage
(More languages will continue to be updated)

Motor Instruction

- 1, Short press the Switch Button to power on
- 2, Long press Button A[3] to the expected point, release it to stop, press Multi-function Button[4] to set point A;
- Long press Button B[5] to the expected point, release it to stop, then press Multi-function Button[4] to set point B.
- After confirming Point A&B
- press Multi-function Button[4] to enter video mode
- (When using the motor, Buffer mode is on by default)
- 3.After setting Point A&B,
- press Button A[3], the motor will move towards Point A;
- Press Button B[5], then the motor will move towards Point B.
- 4.Press the Multi-function Button[4] to adjust the speed:
- Fast-Medium-Slow

Working mode

When the module is on, turn on the Bluetooth and “YC Onion” App, then click the name of gimbal in the product category. After searching successfully, click the device to connect immediately.



Specifications

Name	Chocolate Milk Slider
Model	ESC_B
Size	65*60*78mm
Weight	261.5g
Screw Standard	3/8 screw on the top, 3/8 screw hole at the bottom (1/4 screw adapter is included)
Function	Video Shot, Time Lapse and 4-Axis Interlink System
Material	Aluminum Alloy
Run Time	CANON LP-E6 battery can last around 3 hours/ 10000mAh power bank can last around 15 hours
APP Compatibility	IOS10 or later, Android 5.1 or later

DISCLAIMER

- 1.The Company assumes no liability for any risks related to or resulting from the debug and use of this product (including the direct, indirect or third-party losses).
- 2.For any unknown sources of acquitting this product, we will not be at any services.
- 3.The updating and changes of product firmware and program may cause changes in function descriptions in this user manual, please read the instructions carefully before upgrading the firmware and use the corresponding user manual.
- 4.There may be a description that does not conform to this specification after firmware upgrade of the product Please be subject to the latest product information which is issued in official website.
- 5.The Company reserves all rights of interpretation to

WARRANTY INFORMATION

USER INFORMATION

NAME _____ TEL _____

NMAIL _____ ADD _____

PRODUCTS INFORMATION

PRODUCT NAME _____

PRODUCT MODEL _____

DATE OF PRODUCTION _____

WARRANTY PERIOD _____

TERMS OF WAPPANTY

- 1.Warranty period is 1 year , which begins from the purchasing date.
- 2.No warranty for disassembly without authorization or damage caused by human.

ECS_A_UM_1.0

